

Goof Proof® Numbers Application Instructions

• For application on cotton, polyester or poly/cotton blends.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 360° - 370°F

Time: 3-5 Seconds

Pressure: Med/Firm 6-8 (60-80psi)

2. Preheat Your Apparel

• Place apparel on platen and press for 3-5 seconds

3. Position Your Transfer & Press

- Place number and/or name transfer image side down on the apparel
- Close machine and press for 3-5 seconds

4. Peel Transfer Carrier Hot

• Open machine and peel off the paper backing in a smooth, even motion.

Tips:

- Do not use a pillow
- With normal application, no cover sheet is needed.
A cover sheet could possibly block heat from reaching the application.
- This product can also be applied at 340°F for 8-10 seconds, peeling warm (wait 5 seconds)
- For double digit numbers and/or a name, simply align the paper edges together

Resources:

[TransferExpress.com/videos](https://www.transferexpress.com/videos)

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business.
[TransferExpress.com/webinars](https://www.TransferExpress.com/webinars)

Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

Have a question?

Email us at info@TransferExpress.com

TransferExpress.com
1-800-622-2280

Monday- Friday
8 am - 6 pm ET

info@TransferExpress.com

Join our social community for the latest products, services & tips!



STAHL'S
TRANSFER EXPRESS