

# CAD-PRINTZ® Window Decals

- Printed on a carrier to make application to any window easy.

## 1. Clean Surface

- Always apply graphic to a smooth, clean, dry surface.

## 2. Remove Graphic

- Carefully remove graphic from paper liner. Avoid adhesive to adhesive contact. If this occurs, gently pull apart.

## 3. Position

- Start with one end or corner of design and apply.

## 4. Smooth

- Smooth design with a straight edge tool such as a squeegee or credit card.

## 5. Remove

- Start at one corner of the design; slowly remove the transfer tape carefully pulling at a 180° angle.

*\* Your design will arrive masked with a transfer tape on the logo side and is mounted on a paper backing.*

### Tips:

- Moisten surface with soapy water to aid in positioning.

### Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. [TransferExpress.com/webinars](http://TransferExpress.com/webinars)

Join our social community for the latest products, services & tips!

[TransferExpress.com/SocialCommunity](http://TransferExpress.com/SocialCommunity)



### Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

### Have a question?

Email us at [info@TransferExpress.com](mailto:info@TransferExpress.com)

TransferExpress.com  
1-800-622-2280

Monday- Friday  
8am-10 pm EST

[info@TransferExpress.com](mailto:info@TransferExpress.com)

