

Elasti Prints® Application Instructions

- For application on 100% polyester
- An extra transfer is provided for testing purposes
- Before applying, check your transfers for spelling, color placement, etc.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 290°F

Time: 15 Seconds

Pressure: Med/Firm 6-8 (60-80psi)

2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

3. Position Your Transfer & Press

- Place the transfer image side down on the apparel
- Close machine and press for 15 seconds

4. Peel Transfer Carrier Cold

- Open machine and allow the print to cool completely to the touch.
- Peel off the paper backing in a smooth, even motion.

Tips:

- Do not use a pillow
- With normal application, no cover sheet is needed.
A cover sheet could possibly block heat from reaching the application.
- For 100% polyester only, this product can also be applied at 275°F for 15 seconds, peeling cold.

Resources:

[TransferExpress.com/videos](https://www.transferexpress.com/videos)

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business.
[TransferExpress.com/webinars](https://www.TransferExpress.com/webinars)

Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

Have a question?

Email us at info@TransferExpress.com

TransferExpress.com
1-800-622-2280

Monday- Friday
8 am - 7 pm ET

info@TransferExpress.com

Join our social community for the latest products, services & tips!



STAHL'S
TRANSFER EXPRESS