

# Glitter Application Instructions

- For application on cotton, polyester or poly/cotton blends.
- An extra transfer is provided for testing purposes
- Before applying, check your transfers for spelling, color placement, etc.

## 1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

**Temperature:** 365°F

**Time:** 15 Seconds

**Pressure:** Med/Firm 6-8 (60-80psi)

## 2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

## 3. Position Your Transfer & Press

- Place the transfer image side down on the apparel
- Cover transfer with provided cover sheet to eliminate static
- Close machine and press for 15 seconds

## 4. Peel Cold

- Open machine and allow the print to cool completely to the touch (this may take several minutes).
- Peel off the paper backing in a smooth, even motion.

## OPTIONAL STEP - For a matte pearl finish

- Cover with provided cover sheet and re-press for 8 seconds
- Peel cover sheet hot, immediately when the press opens.

### Tips:

- Do not use a pillow

### Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business.  
[TransferExpress.com/webinars](http://TransferExpress.com/webinars)

### Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

### Have a question?

Email us at  
[info@TransferExpress.com](mailto:info@TransferExpress.com)

[TransferExpress.com](http://TransferExpress.com)  
1-800-622-2280  
Monday- Friday  
8 am - 6 pm ET

### Application Videos

[TransferExpress.com/videos](http://TransferExpress.com/videos)

