

UltraColor® MAX Application Instructions

- For application on cotton, polyester, poly/cotton blends, triblends, Lycra/Spandex
- Before applying, check your transfers for spelling, color placement, etc.
- **Cut off the colored striped lines on the side before applying.**

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 290°F

Time: 12-15 Seconds

Pressure: Med/Firm 5-7 (50-70psi)

2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

3. Position Your Transfer & Press

- Place the transfer with the ink side facing down on the apparel. Your design will be visible through the carrier film.
- Close machine and press for 12-15 seconds

4. Peel Transfer Carrier Hot

- Open machine and peel off the backing in a smooth, even motion.

Tips:

- Keep the silica gel pack stored with your unused UltraColor Max transfers to keep moisture removed from transfers
- Do not use a cover sheet
- Yellowing of adhesive or waffle texture on the carrier is possible and normal; this will not affect application.

Resources:

[TransferExpress.com/videos](https://www.transferexpress.com/videos)

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. [TransferExpress.com/webinars](https://www.TransferExpress.com/webinars)

Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers, stored with the silica gel pack.

Have a question?

[TransferExpress.com](https://www.TransferExpress.com)

1-800-622-2280

info@TransferExpress.com

Monday- Friday

8 am - 6 pm ET

Join our social community for the latest products, services & tips!



STAHL'S
TRANSFER EXPRESS