



The Custom Transfer People

Heat Transfer Placement and Position



1. Putting a full size print too low or a "belly print"




Incorrect




CORRECT



Two Techniques for Full Front Placement
Note: Techniques work best for a square design, slight adjustments
will need to be made if rectangular





From tag find vertical center, intersect with the imaginary line from the bottom of arm seam to arm seam and center

Measure or use three fingers from neck seam



2. Going too far left








Two techniques for a left chest Print



Center on the intersection of the imaginary line between bottom arm seams and a line drawn down from the edge of the collar



Measure 7.5-9" from shoulder seam and 4-6" from center or button center



3. The Tucked-In Number




Incorrect



CORRECT



Use same technique as the front looking at two digits or two digits and name as a single image





4. The Crooked Shorts Print











Unique Transfer Placement













T-shirts







Sweatpants














































Caps











Infographic on Placement will be sent to those attending



Conclusion

Go to www.TransferExpress.com/Webinars for a copy of today's webinar slides.

Do you have more questions??

- Email us info@transferexpress.com
- Read our Blog
- Watch our videos and previous webinars
- Trade Shows
- Social Media

Contact us:

Phone: 1-800-622-2280

Fax: 1-800-833-3877

Email: info@transferexpress.com

Web: TransferExpress.com
Our Blog: http://blog.transferexpress.com/





Thank You for Attending

Next Transfer Express Webinar

- Photography for Your T-Shirt Business
- Thursday, April 14
- 2:00 PM

What topics would you like to see covered in a Transfer Express webinar?

Email them to: info@transferexpress.com



www.TransferExpress.com 1-800-622-2280

