

UltraColor™ Stretch Blocker Application Instructions

- For application on cotton, polyester, poly/cotton blends, spandex, Lycra®, woven nylon, sublimated polyester
- An extra transfer is provided for testing purposes
- Before applying, check your transfers for spelling, color placement, etc.
- Trim black registration marks along edge of gang sheets before applying.

Washing Instructions: For best results- Wash inside out, warm; dry on low.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 290-320°F for 100% polyester and synthetics
340-360°F for cotton and cotton/poly blends

Time: 12-15 Seconds

Pressure: Med/Firm 5-7 (50-70psi)

2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

3. Position Your Transfer & Press

- Place the transfer image side down on the apparel
- Cover transfer with provided cover sheet to eliminate static
- Close machine and press for 12-15 seconds

4. When “COLD” - Peel Transfer Carrier

- Open machine and peel off the backing in a smooth, even motion when cold (this may take several minutes to cool completely)

Tips:

- Do not use a pillow
- If you notice edges raising or if the clear outline is more defined due to the fabric color, take your cover sheet, lay over the transfer, close machine for 4 seconds, open the machine and immediately remove cover sheet

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. TransferExpress.com/webinars

Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

Have a question?

Email us at info@TransferExpress.com

TransferExpress.com
1-800-622-2280

info@TransferExpress.com

Monday - Friday
8 am - 6 pm ET

Join our social community for the latest products, services & tips!



STAHL'S
TRANSFER EXPRESS