

HOTRONIX® FUSION IQ™

Quick Start Guide: XF

The Fusion controller has been updated! This guide will help acquaint you with the new features and show you how easy it is to connect your heat press to the cloud. Please read all accompanying safety instructions!

The Home Screen

The selected preset is shown here; tap and hold to see target values


If a preset has multiple steps, your position is shown here; tap an empty circle to jump to that preset step

The status bar provides helpful information and shows you what's going on with your heat press

Current temperature and pressure values are displayed here; tap to set target values for temperature, pressure and time

Taskbar Buttons and Functions

Tap to select from a list of saved presets



Tap a preset to select it

Tap to enter edit mode

Tap to create a new preset

Managers can lock heat press controls so Users cannot change settings

Press is connected to WIFI

Press is connected to the cloud


Tap to configure your heat press



Managers (default password: "M") see all available setup options, while Users can access a limited set

Create and edit press Managers and Users to control access to settings; press statistics are recorded for cloud-synced users

While setting target values, tap the status bar to quickly jump to a value



While setting target values, tap the status bar to quickly jump to a value

Place the heat press into standby mode to enable scheduled automatic heat-up (see Auto-On/Off in Setup)

HOTRONIX® FUSION IQ™


Quick Start Guide: XF

The Fusion controller has been updated! This guide will help acquaint you with the new features and show you how easy it is to connect your heat press to the cloud. Please read all accompanying safety instructions!

Connecting to the Cloud

1. Create your account

1a. Using a phone or computer, browse to <https://iq.hotronix.com> and click “Create Account”



1b. Type in your name and email, select a password and sign up

STAHLS®
Hotronix®

Create Account
We'll send email confirmation instructions.

Name

Email

Password

Password Confirmation


By continuing you agree to our T&C/Privacy Policy

I'm not a robot

reCAPTCHA
Privacy - Terms

Sign up


1c. Click the confirmation link in the email you receive




Your account has been created!

2. Register a Heat Press

2a. Browse to <https://iq.hotronix.com> and click “Manage Heat Presses”



2b. Click “+New Heat Press”



2c. Enter press type, serial number and name your press if desired

Heat Press * denotes required fields

* Machine Type

Air Fusion

Dual Air Fusion

Fusion

* Serial Number

201800000


Name

My Favorite Fusion

Optional: An easy way for you to identify this Heat Press

Create Heat Press Cancel


2d. Click “Create Heat Press” and note the verification code given



2e. On your heat press, enter WIFI settings and connect to your WIFI router or mobile hotspot




2e. On your heat press, enter cloud settings and enter the verification code given by the website



Your heat press has been registered!

3. Create & Assign Users

3a. Browse to <https://iq.hotronix.com> and click “Manage Operators”




3b. Click “+New User”




3c. Enter a name and select a privilege level. Managers can access all press settings while Users can access a limited set. Managers can have a password.


3d. Select your new user and click “Assign Machines” in the sidebar



3e. Select a machine and click “Assign”



3f. On your heat press, enter cloud settings and tap “Manual Sync”



The Reports page will now show any impressions made by these Users!