


1. Switch the screen on with the POWER button.

3. Select the corresponding input HDMI 1 or 2 or PC/VGA with the UP and DOWN keys and press OK.

2. Press input button.



HDMI 1

(Fixt PC)



HDMI 2

(Laptop hdmi)



PC


(laptop vga)

Hint: First connect the laptop to the corresponding cable and then switch the laptop on.

1. Zet het scherm aan met de POWER button.

3. Select de juiste ingang HDMI 1 of 2 of PC/VGA met de UP en DOWN toetsen en druk op OK.

2. druk op de input knop



HDMI 1

(Vaste PC)



HDMI 2

(Laptop hdmi)



PC

(Laptop vga)

Tip: Sluit eerst de overeenkomstige kabel aan op de laptop en start de laptop daarna op.

