

## INSTRUCTION REMOTE CONTROL

- Switch the screen on with the **POWER** (b) button.
- Select the device source using the **UP + DOWN** arrows:



Choose HDMI 1 when using the fixed PC.




Choose **HDMI 2** when connecting a device/laptop using an HDMI cable.



Choose **PC/VGA** when connecting a device/laptop using a VGA cable.

Make sure to first connect the laptop to the HDMI or VGA cable before switching the laptop on.

3Press the INPUT button.



Need assistance?
Contact the audiovisual support line:
020 59 81000