

NEXA AUTOCOLOR®



IR Drying Technology and Product Curing Guide

Field Settings

Disclaimer: Machine set up recommendations are meant as a starting point. Technicians must complete final adjustments based on products selected and local conditions.

REVO Short wave electric IR



Faster Repairs, Better Results.

| Model Name REVO Speed | | | | | | |
|-----------------------|-----------|---|-------------------------------|----------------------|--|--|
| | | Temp | Speed | Distance | Notes: | |
| Body Filler | | 140°F (60°C) | 26"/min | 18" | | |
| Surfacer | | 190°F (88°C) | 20"/min | 18" | | |
| Sealer | | 145°F (63°C) | 28"/min | 18" | | |
| Basecoat | ABP™ | 140°F (60°C) | 28"/min | ~18" | | |
| Clear | P190-6930 | 210°F (99°C) 210°F (99°C) 225°F (107°C) | 15"/min 15"/min 15"/min | ~18" ~18" ~18" | Flash before cure Flash before cure | |



Additional Notes:

- Adjustments needed based on substrate, color, etc.
- Machine is preprogrammed, select which product you are curing on the touch screen, set the distance by
 using the sonar icon on the screen, sonar indicator on the screen will turn green at proper distance. Only
 one pass is required to fully cure.

| Model Name REVO Rapid | | | | | | |
|-----------------------|--------------|-----------|----------|--------|--|--|
| | Temp | Speed | Distance | Notes: | | |
| Body Filler | 140°F (60°C) | 3 minutes | 2' | | | |
| Surfacer | 185°F (85°C) | 8 minutes | 2' | | | |
| Sealer | 145°F (63°C) | 4 minutes | 2' | | | |
| Basecoat | 140°F (60°C) | 4 minutes | 2' | | | |
| Clear | 200°F (93°C) | 8 minutes | 2' | | | |



- Automatically regulates temperature, no adjustments needed.
- Machine is preprogrammed. Select the product applied and push start and the machine will automatically monitor and adjust temperature.

IR Drying Technology and Product Curing Guide

Field Settings

Disclaimer: Machine set up recommendations are meant as a starting point. Technicians must complete final adjustments based on products selected and local conditions.

REVO Short wave electric IR

| Model Name: REVO Spot | | | | | |
|-----------------------|--------------|-----------|----------|--------|--|
| | Temp | Speed | Distance | Notes: | |
| Body Filler | 140°F (60°C) | 3 minutes | 2' | | |
| Surfacer | 185°F (85°C) | 8 minutes | 2' | | |
| Sealer | 145°F (63°C) | 4 minutes | 2' | | |
| Basecoat | 140°F (60°C) | 4 minutes | 2' | | |
| Clear | 200°F (93°C) | 8 minutes | 2' | | |



Additional Notes:

- Automatically adjust temperature
- Machine has two knobs. One to adjust temperature and one to adjust time in minutes. There is a decal on the machine which tells you the parameters that should be used for each type of product your are curing.

| Model Name: REVO Handheld | | | | | | |
|---------------------------|--------------|-----------|------------|--------|--|--|
| | Temp | Speed | Distance | Notes: | | |
| Body Filler | 140°F (60°C) | 2 minutes | 2-4 inches | | | |
| Surfacer | 190°F (88°C) | 2-3 mins | 2-4 inches | | | |
| Sealer | 140°F (60°C) | 2-3 mins | 2-4 inches | | | |
| Basecoat | 140°F (60°C) | 2-3 mins | 2-4 inches | | | |
| Clear | 200°F (93°C) | 3-4 mins | 2-4 inches | | | |
| 1 | | | | | | |



Additional Notes:

- Adjustments needed based on substrate, color, etc.
- Temperature should be monitored with an infrared thermometer. Handheld unit is only meant for sport repairs. When using for spot repairs each coat of the repair process should be individually dried.

Additional Overall Notes:

- Almost every clear will run at the same temperature as long as it is mixed with medium or slow hardener and reducer.
- However there are two differences, AQUABASE® Plus P190-6930 will run at the same temperature but it likes a 5 minute flash after the final coat before curing with REVO. If you put heat on it right away it will occasionally die back a little bit. After a 5 minute flash it works perfectly and maintains clarity. Aquabase Plus P190-6920 can be cured at a higher temperature and is almost immediately buffable.



NEXA AUTOCOLOR®



IR Drying Technology and Product Curing Guide

Field Settings

Disclaimer: Machine set up recommendations are meant as a starting point. Technicians must complete final adjustments based on products selected and local conditions.

Symach Gas catalytic IR

| Model Nam | Model Name Easydry (Arch located in Spraytron Booth) | | | | | |
|------------------------|--|-------------------------------|----------------------|--------------|----------------------|--|
| | | Temp | Speed | Distance | Notes: | |
| Body Filler | | | | | | |
| Surfacer | | | | | | |
| Sealer | P565-3145 | 176°F (80°C) | 40"/min | ~20" | | |
| Basecoat (Dropcoat) | ABP | 131°F (55°C) 122°F (50°C) | 44"/min 64"/min | ~20" ~20" | | |
| Clear | P190-6950 P190-6950 | 176°F (80°C) 230°F (110°C) | 80cm/min 60cm/min | | 1st pass 2nd pass | |



Additional Notes:

- Allow 5 minutes flash between coats. Fans in Spraytron decrease after 1 minute reducing airflow over panels.
- Pulling the trigger on the spray gun or plugging in hand-held venture will keep booth airflow movement higher to improve flash between coats (this is an adjustable setting).

| Model Nam | ne | Kombitron | | | | | |
|-------------|----|------------------|--------------------------------|----------------------|----------|--------------------|--|
| | | | Temp | Speed | Distance | Notes: | |
| Body Filler | | N/A | | | | | |
| Surfacer | | N/A | | | | | |
| Sealer | | N/A | | | | | |
| Basecoat | | N/A | | | | | |
| Clear | | 0-6930 0-6950 | 219°F (104°C) 219°F (104°C) | 40cm/min 40cm/min | | | |
| | | 0-6950 | 230°F (110°C) | 36cm/min | | Bumpers off of car | |



- Minimal air movement to remove solvent from cabin.
- Factory default setting is 1 minute cool down after cure.
- Kombitron arch is set to urn a full pass out and a full pass back. Travel distance is 260 inches or 660 cm.

IR Drying Technology and Product Curing Guide

Field Settings

Disclaimer: Machine set up recommendations are meant as a starting point. Technicians must complete final adjustments based on products selected and local conditions.

Symach Gas catalytic IR

| Model Name: Flydry | | | | | | |
|--------------------|-----------|---------------|----------|----------|--------|--|
| | | Temp | Speed | Distance | Notes: | |
| Body Filler | | | | | | |
| Surfacer | | | | | | |
| Sealer | | | | | | |
| Basecoat | | | | | | |
| Clear | P190-6920 | 220°F (104°C) | 22cm/min | 40-50 cm | 1 Pass | |



- The robot automatically manages the drying treatment for distance, color, paint thickness and climate.
- The automatic adjustment and control of the treatment are based on a built-in laser that constantly reads the quality of the drying process.



NEXA AUTOCOLOR®



IR Drying Technology and Product Curing Guide

Field Settings

Disclaimer: Machine set up recommendations are meant as a starting point. Technicians must complete final adjustments based on products selected and local conditions.

GreenTech Gas Catalytic IR

| Model Name E6 | | | | | | |
|---------------|-----|---------|--|-------------------------------------|----------------------|----------------------------------|
| | | | Temp | Speed | Distance | Notes: |
| Body Filler | | N/A | | | | |
| Surfacer | P5 | 65-5405 | 230°F (110°C) | 70cm/min | 60cm | 1st and 2nd pass |
| Sealer | P5 | 65-3145 | 248°F (120°C) | 120cm/min | 60cm | 1 pass |
| Basecoat | | ABP | 113°F (45°C) | 145cm/min | 60cm | 1 pass |
| Clear | P19 | 90-6950 | 194°F (90°C) 266°F (130°C) 266°F (130°C) | 120cm/min 110cm/min 100cm/min | 60cm 60cm 60cm | 1st pass 2nd pass 3rd pass |



Additional Notes:

Model Name

Use paper or aluminum foil to protect mirrors.

E7

- 30-60 second pauses can/should be used for curing clears on bumpers and flat edges of vehicles/panels that the robot doesn't directly pass over.
- For surfacer, can use sealer setting to flash off between coats.

| | Temp | Speed | Distance | Notes: |
|-------------|---|-------------------------------------|----------------------|----------------------------------|
| Body Filler | 176°F (80°C) | 100cm/min | 50cm | 1 pass |
| Surfacer | 176°F (80°C) | 80cm/min | 50cm | 1st and 2nd pass |
| Sealer | 140°F (60°C) | 160cm/min | 50cm | 1 pass |
| Basecoat | 104°F (40°C) | 155cm/min | 50cm | 1 pass |
| Clear | 212°F (100°C) 212°F (100°C) 212°F (100°C) | 105cm/min 130cm/min 125cm/min | 50cm 50cm 50cm | 1st pass 2nd pass 3rd pass |



- No settings on the software to monitor temp so this is done with an external temp gun during the set up phase.
- 30-60 second pauses can/should be used for curing clears on bumpers and flat edges of vehicles/panels that the robot doesn't directly pass over.
- For surfacer, can use sealer setting to flash off between coats.

IR Drying Technology and Product Curing Guide

Field Settings

Disclaimer: Machine set up recommendations are meant as a starting point. Technicians must complete final adjustments based on products selected and local conditions.

GreenTech Gas Catalytic IR

| Model Name: E1 (handheld) | | | | | | |
|---------------------------|---------------|-------|----------|--------|--|--|
| | Temp | Speed | Distance | Notes: | | |
| Body Filler | 176°F (80°C) | | 5-10cm | | | |
| Surfacer | 176°F (80°C) | | 5-10cm | | | |
| Sealer | 158°F (70°C) | | 5-10cm | | | |
| Basecoat | 122°F (50°C) | | 5-10cm | | | |
| Clear | 212°F (100°C) | | 5-10cm | | | |



- During curing time the process after the panel reaches the products desired temp. Hold the temp for 2 minutes except for clears where it is 4-7 minutes.
- Slow and smooth circular movement to ensure full/complete curing of the whole product area.
- For surfacer can use sealer settings to flash off between coats.

Additional Overall Notes:

• The E7 is not listed for use in hazardous environments so sprayed product (base/primer) would only be possible in a 3oz. cup in certain jurisdictions, and clearcoat would presumably have to be applied in a prepdeck / CTOF and then moved elsewhere to be dried. The figures are given from testing in Europe where this product can be installed in a booth, in the US E7 is only really used for drying filler and roller primer.

