

P50xxB/P937xB/P938xB Series Keysight Streamline Series VNA, Thunderbolt 3

CAUTION

Please use ESD Precautions when handling and operating

System Requirements

Description	Requirements
Operating system	Windows 10 (64 bit only) ^a
Available memory	16 GB recommend, 4 GB minimum
Available disk space	2 GB available drive space minimum
Display resolution	1024 x 768 minimum
Recommended CPU	Intel Core i7 10 th Generation or later
Connected with VNA	Thunderbolt™ 3

a. Must install IO Libraries Suite 2021 update or greater.

Installation Procedure


1. Download and install the Keysight IO Libraries Suite from <https://www.keysight.com/find/iosuite>. Follow the installer prompts.
2. Download and install the network analyzer software from <https://www.keysight.com/find/pxiusbvna-firmware>. Follow the installer prompts.
3. Shutdown a PC once the installation is done.
4. Connect the included Thunderbolt 3 cable to either of port on the Network Analyzer rear panel and the other end of the cable directly to a Thunderbolt3 (USB-C) port on the PC.



For P502xB-402 or P5025/6/7/8B-400, connect the control cable and tighten it with the nuts as shown in the image above.

5. Plug in the AC adapter to the back of the instrument and then plug it into the AC power.
6. Press the power button to **power up** the instrument first. Confirm if the Power LED is green.
7. Then, power on the PC, click the **Network Analyzer** icon on the PC desktop to execute the VNA application.
8. Select the required model, then click RUN. Confirm if the instrument status is green. See the Help: Quick Start > SFP Launcher for more information.

Note: When the unit is not detected, reboot PC. If it does not resolve, apply the latest windows update and update the computer BIOS and the thunderbolt driver and firmware.



The P50xxB/P937xB/P938xB VNAs have the right side of the instrument dedicated to air intake and the left side dedicated to



Additional information:

Topic	URL
Product information	http://www.keysight.com/products/P5000B http://www.keysight.com/products/P9370B
Manuals	http://www.keysight.com/manuals/P5000B
Technical support	http://www.keysight.com/support/P5000B
Multiple modules setup	Help: Quick Start > Multiport and Multisite Configuration
Connector Care	http://na.support.keysight.com/pna/connectorcare/Connector_Care.htm
Contacting Keysight	http://www.keysight.com/find/assist

This information is subject to change without notice.

© Keysight Technologies 2021
Edition 2, September 2021



www.keysight.com