

Detachable Battery Pack **BU-11**

 ETK1324078E
 Jul. 13, 2015

The Detachable Battery Packs, BU-11 series are specifically designed for SUMITOMO Fusion Splicers, TYPE-71 series, TYPE-81 series, TYPE-Q101 series and T-55.




Specifications		
Part No.	BU-11S	BU-11
Applicable fusion splicer	TYPE-71 series, TYPE-81 series, TYPE-Q101 series and T-55	
Type	Lithium-ion battery	
Output voltage (rated)	11.1V	
Battery capacity (rated)	2300mAh	4600mAh
Battery capacity indicator	Available	
Battery charger (Option)	BC-11 (with optional AC adapter, ADC-1430S)	
Battery lifespan (Charge cycles)	Typ. 500 cycles	
Operating condition	-10 to +50 degree C/ Non-condensing	
Dimensions	82(W) x 122(L) x 22(H) mm	
Weight	Approx. 210g	Approx. 340g

■Specifications are subject to change without prior notice.

Precautions for Battery Pack

Paying attention to just a few pointers will pay off with a longer battery lifespan and battery life for your fusion splicer. The most important thing is to keep your battery out of the sunlight or a hot car (including not leaving it locked up in a hot trunk during summer). Heat will degrade your battery's performance the most.



■ Temperature

Charge : 0 to +40°C

Discharge : -10 to +50°C

Storage : -20 to +50°C (if stored for less than 1month)

-20 to +40°C (if stored for less than 3months)

-20 to +20°C (if stored for less than 1year)

■ Battery lifespan (Charge cycles)

-“Battery life” means the time your fusion splicer will run before it must be recharged.

-“Battery lifespan” means the total amount of time your battery will last before it may need to be replaced.

Battery lifespan is based on the number of charge/discharge cycles your battery is capable of to retain more than 70% of its original capacity.

-Battery lifespan vary by use, environment, settings and many other factors.

■ Use your battery regularly

-To extend battery lifespan and keep battery indicator accuracy, be sure to go through at least one charge cycle per 3months (charging the battery to 100% and then completely running it down).

-If you are not going to use the splicer, remove the battery pack from the splicer.