

# PIM Master™

# 40 Watts Battery-operated Passive Intermodulation Analyzer

Featuring Distance-to-PIM™ (DTP) The Fastest Way to Pinpoint the Source of PIM

LTE 700 **APT 700 LTE 800** Cellular Band E-GSM Band 700 MHz 700 MHz 800 MHz 850 MHz 900 MHz DCS Band PCS/AWS Bands LTE 2600 **UMTS Band** 1800 MHz 1900/2100 MHz 2100 MHz 2600 MHz



# PIM Master™ Passive Intermodulation Analyzer



# PIM Master™ Overview



PIM Master MW82119A 40 Watts, Battery-operated



Ideal solution for tower mounted Radio Head installations



# PIM Master™ Introduction

Anritsu Company introduces the first battery-operated high power Passive Intermodulation (PIM) testing solution for the major wireless standards in use around the world. PIM is a form of interference generated by passive components that are normally thought of as linear such as connectors, cable assemblies, filters and antennas. However, when subject to high RF power levels found in cellular systems, these devices can generate spurious signals that increase the receiver noise floor and reduce site performance.

The PIM Master accurately measures PIM performance by injecting two CW test tones into the antenna feed network and recording the magnitude of the 3<sup>rd</sup>, 5<sup>th</sup>, or 7<sup>th</sup> order intermodulation products falling in the receive band of the system. The MW82119A is able to perform the following measurements enabling test technicians to quickly find and eliminate PIM problems found at the cell site:

- PIM versus Time
- Noise Floor
- Swept PIM
- Distance-to-PIM<sup>™</sup> (DTP)

The PIM Master's small size and light weight combined with battery operation make it the ideal solution for verifying performance at difficult to access sites such as Remote Radio Head (RRH) installations or indoor Distributed Antenna Systems (DAS). Performing a PIM test at these sites often involves a tower climb or carrying the equipment up a ladder or through small access ports to reach the required point of test. The enhanced portability of the MW82119A enables high power PIM testing where required without heavy lifting and without long extension cords.


The PIM Master includes Anritsu's patented Distance-to-PIM™ (DTP) technology for accurately determining the location of PIM faults both inside the feed system as well as beyond the antenna. This technology becomes critically important for fault finding DAS installations due to the complexity of the feed system and large number of RF interconnects. Without DTP, finding and eliminating PIM requires a process of elimination involving the movement of low PIM loads in the network until the PIM problem disappears. This process is not only time consuming, but it also means that good connections may be opened (and potentially damaged) in the process of locating PIM problems. Distance-to-PIM allows technicians to quickly and efficiently locate PIM sources at a site resulting in quicker site repairs and lower cost.

As with all Anritsu Handheld products, the MW82119A has been designed and tested to rigorous standards for shock, vibration and temperature extremes to ensure reliable service in an outdoor environment.


# 2 x 40 W Test Capability

Even though the package is small and it is battery operated, the MW82119A is a high performance PIM test solution allowing operators to adjust output power from 25 dBm (0.3 Watts) for indoor DAS testing to 46 dBm (40 Watts) for macro site testing. In both indoor and outdoor systems, PIM interference is highly dependent on the power level being transmitted by that system. By matching the PIM test power level more closely to the actual power level used at the site, operators will gain a clearer understanding of the true interference generated by both the RF infrastructure and the environment where the antenna is placed.


# PIM Master™ Overview



Distance-to-PIM (DTP)



PIM vs. Time
PIM Level (dBm) vs. Time (second)



**Swept PIM**PIM Level (dBm) vs. Frequency (MHz)

# Distance-to-PIM™ (DTP)

Distance-to-PIM (DTP) is similar to Distance-to-Fault (DTF), which Anritsu introduced in the Site Master™ in 1997 for identifying the location of impedance mismatches in a feed line. DTP quickly and accurately identifies the location of PIM faults inside the feed system as well as beyond the antenna. This capability eliminates the guesswork involved in isolating PIM sources and speeds site repairs.

Up to 6 markers can be activated in Distance-to-PIM to identify the magnitude and distance to PIM faults found in the system. A trace overlay feature allows real time comparison between the active DTP measurement and a previously saved DTP trace. This capability can be used to compare "before and after" results on a site or to clearly show the distance between an unknown PIM source and a "PIM marker" placed on the antenna radome.

#### PIM vs. Time

The PIM Master includes a PIM versus Time measurement that tracks not only the instantaneous PIM level but also records the maximum PIM level experienced throughout a fixed frequency PIM test. The two test frequencies, transmit power level, intermodulation order (3<sup>rd</sup>, 5<sup>th</sup> or 7<sup>th</sup>) and test duration can be easily adjusted by the user to meet the test requirements.

This mode is useful for dynamic PIM tests as it not only captures the peak PIM value for pass / fail determination but also provides a visual indication of the stability of the system under test. When a limit line is entered in this mode, the color of the PIM magnitude changes to red when the value has exceeded the limit value. The peak value will remain red indicating a failure even if the PIM level returns to a passing level after the dynamic stress has been removed.

#### Swept PIM

When making a Swept PIM measurement, the PIM Master is able to evaluate changes in PIM magnitude versus Intermodulation (IM) frequency. This test is conducted by holding one transmit tone fixed while varying the frequency of the second transmit tone, causing the IM product to "sweep" across a range of frequencies in the receive band of the system. The magnitude of the PIM generated versus frequency is displayed and can be compared to a user-selected pass / fail limit.

PIM measurements are the vector sum of all PIM signals generated on a line at the IM frequency being tested. When multiple PIM sources exist, it is possible for the signals to combine out of phase at a particular test frequency indicating a passing result when the individual PIM levels are actually failures. A swept PIM test varies the IM frequency over a range of frequencies providing the user a clearer picture of the true PIM performance of the system. It is worth mentioning that Distance-to-PIM measurements provide the same function as they also evaluate a range of frequencies rather than a single IM frequency.

# **Remote Control**

The PIM Master can be configured for remote control via WiFi to support a variety of testing scenarios. Line of site distances of >100 m (>328 ft) have been achieved allowing a person on the ground to control the test equipment while a person at the top of the mast makes connections and performs dynamic testing. This capability is also useful for rooftop testing, allowing one person to control the test remotely while following the cable run and performing dynamic tests.

# **Noise Floor Measurement**


Noise Floor measurements are available that monitor the full Rx band or the current IM product frequency with the PIM Master transmitters turned off. This allows the user to quickly check to make sure the spectrum is clear of interference before performing a PIM test.

# Easy to view display

The PIM Master uses the same large, field proven, color touch screen displays found in other Anritsu Handheld products. Five different screen settings are available to enhance visibility in the environment where the test will be performed. This includes a Black & White setting to improve readability in direct sunlight as well as a Night Vision setting to reduce screen brightness for nighttime operation.



# **PIM Master Passive Intermodulation Analyzer Features**



Size: 350 mm x 314 mm x 152 mm (13.8 in x 12.4 in x 6.0 in) Lightweight: 9.0 kg to 12.2 kg (20 lb to 27 lb) depending on frequency option




Connector Panel on the left side of MW82119A


# PIM Master™ Passive Intermodulation Analyzer



# **PIM Report Generation and Certified Training**



Line Sweep Tools (LST) utilized for report generation on a PIM trace



Test Reports generated using Line Sweep Tools (LST)

# Line Sweep Tools for Cable, Antenna, and PIM Analyses

Line Sweep Tools (LST) is a post processing tool to manage and archive measured data from Anritsu's cable & antenna analyzers as well as PIM analyzers. Measured PIM results from different frequency band PIM Analyzers as well as measured data from your SiteMaster™ can be combined together into a single, unified site report.

In one report an operator can have all of the information needed to verify the integrity of an antenna system with the measurements of:

- DIM
- Distance-to-PIM (DTP)
- Return Loss
- Insertion Loss
- Distance-to-Fault (DTF)

Contractors, technicians, and engineers can be more productive with one cohesive tool to learn and use in managing antenna line quality measurements.

# PIM Master™ Certified PIM Measurement Training Course

Specialized PIM Master™ passive intermodulation measurement training is an intense one-day instructor led training course that focuses on making PIM measurements (theory and lab). This is modeled on our successful Site Master™ Certified Line Sweep course.

- · Brief Course Outline
  - Definition and Description
  - How PIM differs from Return Loss
  - · Why is PIM a problem
  - · How to test for PIM
  - PIM testing process
  - Hints for successful testing
  - · Assessing results
- Labs
  - · Hooking up the equipment and confirming proper operation
  - Measuring known good and bad devices
  - Device measurement practice
- Exams
  - Theory and safety
  - · Hands-on practical
- Certification (after passing exams)
  - Certificate of Completion
  - Wallet-sized photo ID

Students will learn technical aspects of PIM measurements, how to set up a PIM measurement, useful examples of what works and what doesn't, interpreting results, and locating the PIM.

# **Customer Support**

Like all Anritsu products, the PIM Master has a range of support products, services and training allowing you to maximize your return-on-investment.

With Anritsu's design know-how and demanding production testing and performance verification you can count on the PIM Master to give you years of reliable, dependable service.

# **PIM Master™ Specifications**

Measurements  PIM vs. Time Noise Floor Distance-to-PIM Swept PIM		
Noise Floor Distance-to-PIM Swept PIM		
Distance-to-PIM Swept PIM	3 <sup>cd</sup> , 5 <sup>th</sup> , and 7 <sup>th</sup> order intermodulation product when in receive band (user selectable)	
Swept PIM	Noise Floor vs. Time at selected IM product frequency Distance and relative magnitude of mutiple PIM sources	
	3 <sup>rd</sup> , 5 <sup>th</sup> , and 7 <sup>th</sup> order intermodulation product when in receive band (user selectable)	
Instrument Setup Parameters		
Frequency	Carrier F1, Carrier F2, Intermodulation Order (3rd, 5th, 7th)	
Amplitude Setup	Ref Value, Scale, Auto Range (On/Off), Amplitude Tone (On/Off) Output Power, Test Duration (1 s to 1,200 s)	
Limit Lines	Limit (Upper/Lower), On/Off, Limit Move, Limit Alarm (On/Off, PASS/FAIL indicator)	
GPS	On/Off, 3.3/5.0 V	
DTP	Cable Velocity, Distance	
PIM Measurement Ranges		
RF Test Power	Two CW tones 25 dBm to 46 dBm, 0.1 dBm steps	
Residual PIM Performance PIM Measurement Range	<-117 dBm, <-125 dBm typical ( 2x 43 dBm test tones) -70 dBm to -130 dBm	
Option	Band	Frequency Range
Option 0700	LTE 700	Tx <sub>1</sub> : 734 MHz to 734.5 MHz, Tx <sub>2</sub> : 746 MHz to 768 MHz Rx <sub>1 ower</sub> : 698 MHz to 717 MHz, Rx <sub>11oper</sub> : 777 MHz to 806 MHz
Option 0702	APT 700	Tx,: 768 MHz to 776 MHz, Tx,: 788 MHz to 807 MHz Rx <sub>Lower</sub> : 713 MHz to 738 MHz, Rx <sub>Uppper</sub> : 825 MHz to 845 MHz
Option 0800	LTE 800	Tx <sub>1</sub> : 791 MHz to 795 MHz, Tx <sub>2</sub> : 811.5 MHz to 821 MHz Rx: 832 MHz to 862 MHz
Option 0850	Cellular 850	Tx <sub>1</sub> : 869 MHz to 871 MHz, Tx <sub>2</sub> : 881.5 MHz to 894 MHz Rx: 824 MHz to 849 MHz
Option 0900	E-GSM 900	Tx <sub>.</sub> ; 925 MHz to 937.5 MHz, Tx <sub>2</sub> ; 951.5 MHz to 960 MHz Rx: 880 MHz to 915 MHz
Option 0180	DCS 1800	Tx,: 1805 MHz to 1837 MHz, Tx,: 1857.5 MHz to 1880 MHz Rx: 1710 MHz to 1785 MHz
Option 0193	PCS/AWS	Tx,: 1930 MHz to 1940 MHz, Tx $_2$ : 1955 MHz to 1995 MHz, Tx $_3$ : 2110 MHz to 2155 MHz, Rx $_3$ : 1850 MHz to 1910 MHz (using Tx $_1$ and Tx $_2$ ), Rx $_2$ : 1710 MHz to 1755 MHz (using Tx $_1$ and Tx $_3$ )
Option 0210	UMTS 2100	Tx,: 2110 MHz to 2112.5 MHz, Tx,: 2130 MHz to 2170 MHz Rx <sub>Lower</sub> : 1920 MHz to 1980 MHz, Rx <sub>Upper</sub> : 2050 MHz to 2090 MHz
Option 0260	LTE 2600	Tx <sub>1</sub> : 2620 MHz to 2630 MHz, Tx <sub>2</sub> : 2650 MHz to 2690 MHz Rx: 2500 MHz to 2570 MHz
PIM Master Connectors		
Test Port	7/16 DIN, female, 50 Ω	
Dual USB Type A USB Mini-B	2x Type A (connect USB Flash Drive and USB Power Sensor)  1x Mini-B (connect to PC for data transfer)	
GPS	SMA, female (with GPS option only)	
External Power	2.1 mm x 5.5 mm barrel connector, 12 to 15 VDC, < 5.0 A	
Display	242 (0.4%) to only a super-	
Size Resolution	213 mm (8.4 in) touch screen 800 x 600	
Battery		
Туре	Li-Ion	
Battery Operation	>3.0 hours, typ	DICAL CONTRACTOR CONTR
Power  Emergency Stop AC/DC Adapter	Red push button Input: 100-240 VAC, 50/60 Hz, Output: 12 VDC	
Electromagnetic Compatibility	,	
Australia and New Zealand	C-tick N274	
Interference	EN 61326-1:2006 EN 55011:2007	
Emissions Immunity	EN 61000-4-2/-4-3/-4-4/-4-5/-4-6/-4-11	
European Union		Directive 2004/108/EC
Safety Class	2006/95/EC, EN 61010-1 Class 1 IEC 60950-1 when used with Anritsu Company supplied power cable	
Product Safety  Environmental	1EC 00320-1 W	nen useu with Anntsu Company supplied power Cable
Operating Temperature	-10 °C to 55 °C	
Relative Humidity	5 % to 95 % at +40 °C, Non-condensing	
at t	MIL-PRF-28800F Class 2	
Shock	-51 °C to 71 °C	
Shock Storage Altitude		pperating and non-operating
Storage		operating and non-operating



# **Ordering Information**



**Model Number** Description

PIM Master™ Passive Intermodulation Analyzer (must be ordered one with ONE frequency option) MW82119A

**Frequency Options** (must order one, and one only)

MW82119A-0700 LTE 700 MW82119A-0702 APT 700 MW82119A-0800 LTE 800 MW82119A-0850 Cellular 850 E-GSM 900 MW82119A-0900 MW82119A-0180 DCS 1800

MW82119A-0193 PCS/AWS 1900/2100

MW82119A-0210 **LIMTS 2100** LTE 2600 MW82119A-0260

**Other Options** 

**Part Number** 

2000-1786-R

2000-1714-R

MW82119A-0019 High Accuracy Power Meter (requires USB power sensor)

MW82119A-0031 GPS Receiver (requires GPS antenna)

MW82119A-0098 Standard Calibration to ISO 17025 and/or Z540.1

MW82119A-0099 Premium Calibration to ISO 17025 and/or Z540.1 plus test data

# Standard Accessories (included with PIM Master)



Description Soft Carrying Case, Screen Access Shoulder Strap Stylus with Coiled Tether

2000-1691-R 2000-1797-R Screen Protector Film, 8.4 in. 1091-422-R Low PIM Adapter, 7/16 DIN(m) to 7/16 DIN(f), 50  $\Omega$ 

2300-577 Anritsu Software Tool Box for Handheld RF Instruments Disc 633-75 High-capacity Li-Ion, Battery Pack

AC/DC Power Supply 40-187-R

(Country dependent) AC Power Cable

Automotive Power Adapter, 12 VDC, 60 W 806-141-R 2000-1371-R Ethernet Cable, 7 ft/213 cm

3-2000-1498 USB A-mini B Cable, 10 ft/305 cm 10920-00060 Handheld Instruments Documentation Disc Three-year warranty (battery one-year warranty)

Certificate of Calibration

# **Optional Accessories**





#### **Part Number** Description

2000-1745-R PIM Master Backpack Accessory Kit 2000-1746-R PIM Master Hard Case Accessory Kit Armored PIM Test Cable, 2.75 m, 7/16 DIN(m) to 7/16 DIN(m), 50  $\Omega$ 16DD50-2.75-R 16DD50-4.0-R Armored PIM Test Cable, 4.0 m, 7/16 DIN(m) to 7/16 DIN(m), 50  $\Omega$ 2000-1626-R PIM Test Cable, 3.0 m, 7/16 DIN(m) to 7/16 DIN(m), 50  $\Omega$ 

PIM Test Cable, 3.0 m, 7/16 DIN(m) to 7/16 DIN(f), 50  $\Omega$ 2000-1783-R 2000-1724-R Low PIM Termination, 700 MHz to 2600 MHz, 40 W, 7/16 DIN(m), 7/16 DIN(f), 50  $\Omega$ 2000-1749-R Low PIM Termination, 700 MHz to 2600 MHz, 10 W, 7/16 DIN(m), 7/16 DIN(f), 50 Ω

1091-390-R PIM Standard, -80 dBm ±3 dB @ 1775 MHz, with 2x 20 W,

7/16 DIN(m) to 7/16 DIN(f), 50  $\Omega$ 

Low PIM Adapter, 7/16 DIN(m) to 7/16 DIN(m), DC to 3 GHz, 50  $\Omega$ 1091-421-R

Low PIM Adapter, 7/16 DIN(m) to 7/16 DIN(f), DC to 3 GHz, 50  $\Omega$ 1091-422-R 1091-423-R Low PIM Adapter, 7/16 DIN(m) to N(m), DC to 3 GHz, 50  $\Omega$ Low PIM Adapter, 7/16 DIN(m) to N(f), DC to 3 GHz, 50  $\Omega$ 1091-424-R

1091-425-R Low PIM Adapter, 7/16 DIN(f) to N(f), DC to 3 GHz, 50  $\Omega$ Low PIM Adapter, 7/16 DIN(f) to N(m), DC to 3 GHz, 50  $\Omega$ 1091-426-R

1091-427-R Low PIM Adapter, 7/16 DIN(f) to 7/16 DIN(f), DC to 3 GHz, 50  $\Omega$ 

Low PIM Adapter, 45°, 7/16 DIN(m) to 7/16 DIN(f), DC to 3 GHz, 50  $\Omega$ 1091-431-R 1091-433-R Low PIM Adapter, 4.1/9.5(f) to 7/16 DIN(f), DC to 3 GHz, 50  $\Omega$ 

Low PIM Adapter, 4.1/9.5(m) to 7/16 DIN(f), DC to 3 GHz, 50  $\Omega$ 1091-434-R 01-510 Adjustable Wrench 01-513-R 1¼" Torque Wrench

67135 Backpack for Accessories

760-259-R Transit Case (holds MW82119A/B PIM Analyzer only)

760-265-R Transit Case (holds MW82119A/B PIM Analyzer plus accessories) 2000-1374 Dual Battery Charger

2000-1528-R GPS Antenna, SMA(m) with 15 ft cable

2000-1652-R GPS Antenna, SMA(m) with 1 ft cable 2000-1760-R GPS Antenna, SMA(m), 25 dB gain

MA24106A High Accuracy RF Power Sensor, 50 MHz to 6 GHz, +23 dBm MA24105A Inline High Power Sensor, 350 MHz to 4 GHz, +3 dBm to +51.76 dBm 10580-00370 Certified PIM Master™ PIM Measurement Training Course

# **Manuals**

**Part Number** Description

10580-00285 User Guide (soft copy on Handheld Instruments Documentation Disc and @ www.anritsu.com)

10920-00060 Handheld Instruments Documentation Disc

# • United States

**Anritsu Company** 

1155 East Collins Boulevard, Suite 100, Richardson, TX, 75081 U.S.A. Toll Free: 1-800-267-4878 Phone: +1-972-644-1777 Fax: +1-972-671-1877

#### • Canada

# Anritsu Electronics Ltd.

700 Silver Seven Road, Suite 120, Kanata, Ontario K2V 1C3, Canada Phone: +1-613-591-2003 Fax: +1-613-591-1006

#### Brazil

# Anritsu Electrônica Ltda.

Praça Amadeu Amaral, 27 - 1 Andar 01327-010 - Bela Vista - São Paulo - SP - Brazil Phone: +55-11-3283-2511 Fax: +55-11-3288-6940

#### Mexico

# Anritsu Company, S.A. de C.V.

Av. Ejército Nacional No. 579 Piso 9, Col. Granada 11520 México, D.F., México Phone: +52-55-1101-2370 Fax: +52-55-5254-3147

#### • United Kingdom Anritsu EMEA Ltd.

200 Capability Green, Luton, Bedfordshire LU1 3LU, U.K. Phone: +44-1582-433280 Fax: +44-1582-731303

#### • France Anritsu S.A.

12 avenue du Québec, Batiment Iris 1-Silic 612, 91140 Villebon-sur-Yvette, France Phone: +33-1-60-92-15-50 Fax: +33-1-64-46-10-65

#### • Germany Anritsu GmbH

Nemetschek Haus, Konrad-Zuse-Platz 1 81829 München, Germany Phone: +49-89-442308-0 Fax: +49-89-442308-55

# • Italy

#### Anritsu S.r.l.

Via Elio Vittorini 129, 00144 Roma Italy Phone: +39-06-509-9711 Fax: +39-06-502-2425

# Sweden

#### Anritsu AB

Kistagången 20B, 164 40 KISTA, Sweden Phone: +46-8-534-707-00 Fax: +46-8-534-707-30

#### • Finland Anritsu AB

# Teknobulevardi 3-5, FI-01530 Vantaa, Finland

Phone: +358-20-741-8100 Fax: +358-20-741-8111

#### Denmark Anritsu A/S

Kay Fiskers Plads 9, 2300 Copenhagen S, Denmark Phone: +45-7211-2200 Fax: +45-7211-2210

#### • Russia

# Anritsu EMEA Ltd.

# Representation Office in Russia

Tverskaya str. 16/2, bld. 1, 7th floor Moscow, 125009, Russia Phone: +7-495-363-1694 Fax: +7-495-935-8962

#### • Spain

#### Anritsu EMEA Ltd.

# **Representation Office in Spain**

Edificio Cuzco IV, Po. de la Castellana, 141, Pta. 8 28046, Madrid, Spain Phone: +34-915-726-761 Fax: +34-915-726-621

#### • United Arab Emirates Anritsu EMEA Ltd. Dubai Liaison Office

P O Box 500413 - Dubai Internet City Al Thuraya Building, Tower 1, Suite 701, 7th floor Dubai, United Arab Emirates Phone: +971-4-3678352 Fax: +971-4-3688460

Please Contact:

#### • India

#### Anritsu India Pvt Ltd.

2nd & 3rd Floor, #837/1, Binnamangla 1st Stage, Indiranagar, 100ft Road, Bangalore - 560038, India Phone: +91-80-4058-1300

#### Singapore

# Anritsu Pte. Ltd.

11 Chang Charn Road, #04-01, Shriro House Singapore 159640 Phone: +65-6282-2400 Fax: +65-6282-2533

# • P. R. China (Shanghai) Anritsu (China) Co., Ltd.

2701-2705, Tower A,

New Caohejing International Business Center No. 391 Gui Ping Road Shanghai, Xu Hui Di District, Shanghai 200233, P.R. China Phone: +86-21-6237-0898 Fax: +86-21-6237-0899

# • P. R. China (Hong Kong) Anritsu Company Ltd.

Unit 1006-7, 10/F., Greenfield Tower, Concordia Plaza, No. 1 Science Museum Road, Tsim Sha Tsui East, Kowloon, Hong Kong, P. R. China Phone: +852-2301-4980 Fax: +852-2301-3545

#### Japan

# **Anritsu Corporation**

8-5, Tamura-cho, Atsugi-shi, Kanagawa, 243-0016 Japan Phone: +81-46-296-1221 Fax: +81-46-296-1238

#### Korea

# Anritsu Corporation, Ltd.

SFL, 235 Pangyoyeok-ro, Bundang-gu, Seongnam-si, Gyeonggi-do, 463-400 Korea Phone: +82-31-696-7750 Fax: +82-31-696-7751

# • Australia

# Anritsu Pty Ltd.

Unit 21/270 Ferntree Gully Road, Notting Hill, Victoria 3168, Australia Phone: +61-3-9558-8177 Fax: +61-3-9558-8255

#### • Taiwan

# Anritsu Company Inc.

7F, No. 316, Sec. 1, Neihu Rd., Taipei 114, Taiwan Phone: +886-2-8751-1816 Fax: +886-2-8751-1817



The Master Users Group is an organization dedicated to providing training, technical support, networking opportunities and links to Master product development teams. As a member you will receive the Insite Quarterly Newsletter with user stories, measurement tips, new product news and more.

Visit us to register today: www.anritsu.com/MUG

# Training at Anritsu

Anritsu has designed courses to help you stay up to date with technologies important to your job.

For available training courses visit: www.anritsu.com/training



Anritsu utilizes recycled paper and environmentally conscious inks and toner.





® Anritsu All trademarks are registered trademarks of their respective owners. Data subject to change without notice. For the most recent specifications visit: www.anritsu.com MW82119A PIM Master PB ©2015 Anritsu Company, USA All Rights Reserved.



